

Title	Semi-Volatile Organic Compounds
Test Explanation:	The SVOC test includes EPA regulated Synthetic Organic Chemicals on the National Primary Drinking Water list, banned pesticides and insecticides, and PAHs, Poly-aromatic Hydrocarbons found in coal and in tar deposits.
Specimen Requirements	<p>Samples for SVOC analysis will only be accepted from the Indiana State Department of Health and other government agencies.</p> <p>If you require a test for a specific organic chemical, please ask.</p> <p>Contact: Mark Starzynski 317-921-5580 for sample containers and instructions.</p>
Sampling Materials	<p>Water must be collected in one liter glass bottles with teflon lined caps, both of which were previously rinsed with solvents.</p> <p>Solids are collected in solvent rinsed pint glass jars with clean aluminum foil between the jar and the cap.</p>
Procedural Notes	<p>Water - fill 2 of the provided one liter glass bottles to the top.</p> <p>Solid - fill 1 of the provided pint glass jars with the solid.</p>
Shipping Instructions	<p>Samples must be kept refrigerated at 4°C from the time of collection to the time of analysis. Samples should be delivered to the laboratory within 1 day of collection. Ship samples by an overnight service with ice packs and adequate padding to prevent breakage, or hand-deliver to the lab.</p> <p>Indiana State Department of Health Chemistry Laboratories 550 W. 16th Street, Suite B Indianapolis, In 46202</p>
Reporting and TAT	Results will be e-mailed to the submitter normally within 30 days.